



# HiKey970

## Switch Mode Guide

Issue	01
Date	2018-03-11

**Copyright © HiSilicon Technologies Co., Ltd. 2018. All rights reserved.**

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of HiSilicon Technologies Co., Ltd.

## **Trademarks and Permissions**



**HISILICON**, and other HiSilicon icons are trademarks of HiSilicon Technologies Co., Ltd.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

## **Notice**

The purchased products, services and features are stipulated by the contract made between HiSilicon and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

## **HiSilicon Technologies Co., Ltd.**

Address: Huawei Industrial Base  
Bantian, Longgang  
Shenzhen 518129  
People's Republic of China

Website: <http://www.hisilicon.com>

Email: [support@hisilicon.com](mailto:support@hisilicon.com)



## Change History

---

Changes between document issues are cumulative. The latest document issue contains all the changes made in earlier issues.

### **Issue 01 (2018-03-11)**

The first version.



# Contents

---

Change History .....	i
Contents .....	ii
1 Switch Mode Guide .....	1



# 1 Switch Mode Guide

**Figure 1-1** Sw2404 mode

Switch	Normal Mode	Fastboot Mode	Recovery Mode
Switch 1	ON	ON	ON
Switch 2	OFF	OFF	ON
Switch 3	OFF	ON	ON

